



DTEN Setting

Proximity Signal

August 2023

Table of Contents

Table of Contents	3
Overview	4
Supporting Product	4
Designed Use Case	4
Setup Instructions	4
Prerequisites	4
Step-by-step instructions	4
Known Issues	6



Overview

There are situations where the proximity sound may be interrupting the meeting experience due to interfering with the microphone frequency. To mitigate this issue, the user can now adjust the proximity signal strength through the DTEN device settings.

Supporting Product

D7X 55 & 75 Windows

Designed Use Case

If a buzzing noise occurs in a meeting, users can adjust the proximity signal. This will reduce the noise and improve users' meeting experience.

**If users are not experiencing any noise issues, there is no need to change this setting.*

Setup Instructions


Prerequisites

- DTEN minimum version: 3.5.0
- Zoom Room minimum version: 5.13
- Sign in to your Zoom Rooms account


Step-by-step instructions

1. While on the Zoom homepage, press the "Menu" button on the back to access the hardware options.
2. Enter the Dashboard.





3. Click on "Settings."
4. Click on "Proximity Signal"



5. Select either Moderate or Disabled (The default is set to Aggressive, If users are experiencing any noise issues, they can try Moderate or Disabled to resolve the noise issue.)

Proximity Signal Aggressive ^

For content sharing through Zoom applications

Disabled

Moderate

Aggressive ✓

Cancel

Save

Known Issues

None